

По вопросам продаж и поддержки обращайтесь:

**Алматы** (7273)495-231  
**Ангарск** (3955)60-70-56  
**Архангельск** (8182)63-90-72  
**Астрахань** (8512)99-46-04  
**Барнаул** (3852)73-04-60  
**Белгород** (4722)40-23-64  
**Благовещенск** (4162)22-76-07  
**Брянск** (4832)59-03-52  
**Владивосток** (423)249-28-31  
**Владикавказ** (8672)28-90-48  
**Владимир** (4922)49-43-18  
**Волгоград** (844)278-03-48  
**Вологда** (8172)26-41-59  
**Воронеж** (473)204-51-73  
**Екатеринбург** (343)384-55-89  
**Иваново** (4932)77-34-06  
**Ижевск** (3412)26-03-58  
**Иркутск** (395)279-98-46  
**Казань** (843)206-01-48

**Калининград** (4012)72-03-81  
**Калуга** (4842)92-23-67  
**Кемерово** (3842)65-04-62  
**Киров** (8332)68-02-04  
**Коломна** (4966)23-41-49  
**Кострома** (4942)77-07-48  
**Краснодар** (861)203-40-90  
**Красноярск** (391)204-63-61  
**Курган** (3522)50-90-47  
**Курск** (4712)77-13-04  
**Липецк** (4742)52-20-81  
**Магнитогорск** (3519)55-03-13  
**Москва** (495)268-04-70  
**Мурманск** (8152)59-64-93  
**Набережные Челны** (8552)20-53-41  
**Нижний Новгород** (831)429-08-12  
**Новокузнецк** (3843)20-46-81  
**Новосибирск** (383)227-86-73  
**Ноябрьск** (3496)41-32-12

**Омск** (3812)21-46-40  
**Орел** (4862)44-53-42  
**Оренбург** (3532)37-68-04  
**Пенза** (8412)22-31-16  
**Пермь** (342)205-81-47  
**Петрозаводск** (8142)55-98-37  
**Псков** (8112)59-10-37  
**Ростов-на-Дону** (863)308-18-15  
**Рязань** (4912)46-61-64  
**Самара** (846)206-03-16  
**Санкт-Петербург** (812)309-46-40  
**Саранск** (8342)22-96-24  
**Саратов** (845)249-38-78  
**Севастополь** (8692)22-31-93  
**Симферополь** (3652)67-13-56  
**Смоленск** (4812)29-41-54  
**Сочи** (862)225-72-31  
**Ставрополь** (8652)20-65-13  
**Сургут** (3462)77-98-35

**Сыктывкар** (8212)25-95-17  
**Тамбов** (4752)50-40-97  
**Тверь** (4822)63-31-35  
**Тольятти** (8482)63-91-07  
**Томск** (3822)98-41-53  
**Тула** (4872)33-79-87  
**Тюмень** (3452)66-21-18  
**Улан-Удэ** (3012)59-97-51  
**Ульяновск** (8422)24-23-59  
**Уфа** (347)229-48-12  
**Хабаровск** (4212)92-98-04  
**Чебоксары** (8352)28-53-07  
**Челябинск** (351)202-03-61  
**Череповец** (8202)49-02-64  
**Чита** (3022)38-34-83  
**Якутск** (4112)23-90-97  
**Ярославль** (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +7(7172)727-132

**Киргизия** +996(312)96-26-47

сайт: [www.honeywell.nt-rt.ru](http://www.honeywell.nt-rt.ru) || эл. почта: [hwn@nt-rt.ru](mailto:hwn@nt-rt.ru)

# СЕТЕВЫЕ АДАПТЕРЫ

Руководство пользователя на  
ВАСА-А

## BACnet WiFi Adapter (BACA-A)

### MOUNTING AND OPERATING INSTRUCTIONS

Keep these instructions together with the device or with the equipment documentation!

**! CAUTION:** To comply with FCC RF exposure compliance requirements, the BACnet WiFi Adapter must be installed at such a location as to ensure that it is always separated from all persons by a distance of at least 20 cm when in operation! It is prohibited to co-locate or operate it in conjunction with any other transmitter.


### PURPOSE:

The BACnet WiFi Adapter talks BACnet IP via WiFi and includes a router to BACnet MS/TP. It can be used for commissioning and debugging BACnet systems.


### CYBER SECURITY:

After use, the BACnet WiFi Adapter should not be left on site and/or connected with the controller or BACnet bus. Rather, it should be disconnected and stored in a secure place. This is to prevent unauthorized system access.

#### 0A. FRONT / REAR VIEWS



#### 0B. POWER




# STANDARD PROCEDURE (STEPS 01A – 06A) FOR CONNECTING BACNET WIFI ADAPTER TO NETWORK – WHEN USING MOBILE DEVICE RUNNING ON ANDROID OPERATING SYSTEM


01A. OPEN YOUR MOBILE DEVICE. "SETTINGS – CONNECTIONS – WiFi." FROM THE LIST OF AVAILABLE NETWORKS, SELECT "Honeywell BACnet NETWORK" (BACA-A DEFAULT FACTORY WiFi NAME IS "Honeywell-BACnet").



02A. IF PROMPTED, TYPE IN THE NETWORK PASSWORD.



03A. FOR NETWORK PASSWORD AFTER A FACTORY RESET, SEE THE LABEL ON THE BOTTOM OF THE HOUSING.



04A. THEN TOUCH THE "CONNECT" BUTTON. THE CONNECTION PROCESS WILL THEN RUN FOR A WHILE.









05A. THEN CLICK "KEEP WiFi CONNECTION." THE CONNECTION WILL THEN BE ESTABLISHED.



06A. IF THE NETWORK YOU HAVE SELECTED IS LISTED AS "CURRENT NETWORK," YOUR NETWORK CONNECTION HAS BEEN ESTABLISHED!




### WPS PROCEDURE (STEPS 01B – 06B) FOR CONNECTING BACNET WIFI ADAPTER TO NETWORK – WHEN USING MOBILE DEVICE RUNNING ON ANDROID OPERATING SYSTEM SOFTWARE VERSION 8 OR EARLIER

<p><b>01B. ESTABLISH WIFI CONNECTION</b></p>  <p>SMART NETWORK SWITCH AUTOMATICALLY SWITCH BETWEEN WI-FI AND MOBILE NETWORKS...</p> <p><b>Wi-Fi NETWORKS</b></p> <ul style="list-style-type: none"><li>Honeywell-BACnet SECURED</li><li>heatappSmile SECURED WPS AVAILABLE</li><li>TAC SECURED WPS AVAILABLE</li></ul>	<p><b>02B. SELECT "WPS PUSH BUTTON"</b></p>  <p>SMART NETWORK SWITCH AUTOMATICALLY SWITCH BETWEEN WI-FI AND MOBILE NETWORKS...</p> <p><b>Wi-Fi NETWORKS</b></p> <ul style="list-style-type: none"><li>WI-FI DIRECT</li><li>ADVANCED</li><li><b>WPS PUSH BUTTON</b></li></ul>
<p><b>03B. START THE WPS PUSH BUTTON SET-UP</b></p>  <p><b>WPS SET-UP</b></p> <p>TAP THE WI-FI PROTECTED SET-UP BUTTON ON YOUR ROUTER. IT MAY BE CALLED WPS OR CONTAIN THIS SYMBOL:</p>  <p>CANCEL</p>	<p><b>04B. WPS SET-UP COMPLETE</b></p>  <p>SMART NETWORK SWITCH AUTOMATICALLY SWITCH BETWEEN WI-FI AND MOBILE NETWORKS...</p> <p><b>WPS SET-UP</b></p> <p><b>WPS COMPLETE. CONNECTING TO THE NETWORK...</b></p>  <p>CANCEL</p>

05B. WIFI CONNECTION ESTABLISHED







06B. OPTIONAL CONFIGURATION



07. SEE ALSO:



- 

**ComfortPoint Open CPO-Rxx ROOM CONTROLLERS...**
  - DATA SHEET (EN0B-0732GE51)
  - INSTALLATION & COMM. INSTRUCTIONS (EN1B-0591GE51)
- 

**BACnet WiFi Adapter...**
  - PRODUCT DATA (EN0B-0733GE51)
  - MOUNTING & OPER. INSTRUCTIONS (MU1B-0592GE51)

08. SPECIFICATIONS

PURPOSE:	OPERATING CONTROL
CONSTRUCTION:	INDEPENDENTLY MOUNTED
ACTION TYPE:	1
POLLUTION DEGREE:	2
SOFTWARE CLASS:	A
RATED IMPULSE VOLTAGE:	500 V

По вопросам продаж и поддержки обращайтесь:

**Алматы** (7273)495-231  
**Ангарск** (3955)60-70-56  
**Архангельск** (8182)63-90-72  
**Астрахань** (8512)99-46-04  
**Барнаул** (3852)73-04-60  
**Белгород** (4722)40-23-64  
**Благовещенск** (4162)22-76-07  
**Брянск** (4832)59-03-52  
**Владивосток** (423)249-28-31  
**Владикавказ** (8672)28-90-48  
**Владимир** (4922)49-43-18  
**Волгоград** (844)278-03-48  
**Вологда** (8172)26-41-59  
**Воронеж** (473)204-51-73  
**Екатеринбург** (343)384-55-89  
**Иваново** (4932)77-34-06  
**Ижевск** (3412)26-03-58  
**Иркутск** (395)279-98-46  
**Казань** (843)206-01-48

**Калининград** (4012)72-03-81  
**Калуга** (4842)92-23-67  
**Кемерово** (3842)65-04-62  
**Киров** (8332)68-02-04  
**Коломна** (4966)23-41-49  
**Кострома** (4942)77-07-48  
**Краснодар** (861)203-40-90  
**Красноярск** (391)204-63-61  
**Курган** (3522)50-90-47  
**Курск** (4712)77-13-04  
**Липецк** (4742)52-20-81  
**Магнитогорск** (3519)55-03-13  
**Москва** (495)268-04-70  
**Мурманск** (8152)59-64-93  
**Набережные Челны** (8552)20-53-41  
**Нижний Новгород** (831)429-08-12  
**Новокузнецк** (3843)20-46-81  
**Новосибирск** (383)227-86-73  
**Ноябрьск**(3496)41-32-12

**Омск** (3812)21-46-40  
**Орел** (4862)44-53-42  
**Оренбург** (3532)37-68-04  
**Пенза** (8412)22-31-16  
**Пермь** (342)205-81-47  
**Петрозаводск** (8142)55-98-37  
**Псков** (8112)59-10-37  
**Ростов-на-Дону** (863)308-18-15  
**Рязань** (4912)46-61-64  
**Самара** (846)206-03-16  
**Санкт-Петербург** (812)309-46-40  
**Саранск** (8342)22-96-24  
**Саратов** (845)249-38-78  
**Севастополь** (8692)22-31-93  
**Симферополь** (3652)67-13-56  
**Смоленск** (4812)29-41-54  
**Сочи** (862)225-72-31  
**Ставрополь** (8652)20-65-13  
**Сургут** (3462)77-98-35

**Сыктывкар** (8212)25-95-17  
**Тамбов** (4752)50-40-97  
**Тверь** (4822)63-31-35  
**Тольятти** (8482)63-91-07  
**Томск** (3822)98-41-53  
**Тула** (4872)33-79-87  
**Тюмень** (3452)66-21-18  
**Улан-Удэ** (3012)59-97-51  
**Ульяновск** (8422)24-23-59  
**Уфа** (347)229-48-12  
**Хабаровск** (4212)92-98-04  
**Чебоксары** (8352)28-53-07  
**Челябинск** (351)202-03-61  
**Череповец** (8202)49-02-64  
**Чита** (3022)38-34-83  
**Якутск** (4112)23-90-97  
**Ярославль** (4852)69-52-93

**Россия** +7(495)268-04-70

**Казахстан** +7(7172)727-132

**Киргизия** +996(312)96-26-47

сайт: [www.honeywell.nt-rt.ru](http://www.honeywell.nt-rt.ru) || эл. почта: [hwn@nt-rt.ru](mailto:hwn@nt-rt.ru)