По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231 **Ангарск** (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 **Благовещенск** (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владимир (4922)49-43-18 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06 Ижевск (3412)26-03-58 **Иркутск** (395)279-98-46

Казань (843)206-01-48

Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курган (3522)50-90-47 Курск (4712)77-13-04 Липецк (4742)52-20-81 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Ноябрьск(3496)41-32-12

Омск (3812)21-46-40 **Орел** (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 **Санкт-Петербург (**812)309-46-40 Саранск (8342)22-96-24 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17 Тамбов (4752)50-40-97 **Тверь** (4822)63-31-35 Тольятти (8482)63-91-07 TOMCK (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 **У**лан-Удэ (3012)59-97-51 Ульяновск (8422)24-23-59 **Yda** (347)229-48-12 Хабаровск (4212)92-98-04 Чебоксары (8352)28-53-07 Челябинск (351)202-03-61 Череповец (8202)49-02-64 **Чита** (3022)38-34-83 Якутск (4112)23-90-97 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

сайт: www.honeywell.nt-rt.ru || эл. почта: hwn@nt-rt.ru

РЕГУЛЯТОРЫ ДАВЛЕНИЯ

Технические характеристики на HON 655-DP, HON 655-EP



RMG 655-EP

Features and Benefits:

RMG 655-EP is a pilot with electric/pneumatic loading pressure stage according to DIN EN 334.

The pneumatic pressure control stages monitor the preset limit values. As soon as outlet pressure gets close to these limits during operation, the pneumatic pressure control stages take over and keep the pressure constant. The transition from electronic control to pneumatic control is done automatically and is operated smoothly in both directions.

The following operation modes may be realized between the two pressure limits: Remote setpoint adjustment

Adaptation of setpoints due to frequently changing operating conditions
Integration with process control systems
Flow control, optimising efficient gas supply
Gas storage in networks and tanks
Meter protection by means of actual flow limitation
Pressure control
Meter protection by means of actual flow limitation
According to defined pressure curves throughout a day or week
To improve regulating accuracy and stability due to electronic PI or PID control

CE registration according to PED in combination with RMG gas pressure regulators According to DIN EN 334, the pilot is an integral component of this device Max. admissible pressure PS = 100 bar

Max. inlet pressure pu max: up to 100 bar

Pilot HON 655-EP consists of functional modules on a common base plate:

1st stage: Automatic load-limiting stage

2nd stage: Pilot stage for the upper outlet pressure limit pd max, optionally pd min

3rd stage: Electro-pneumatic loading pressure stage converting electrical signals into pneumatic signals

All mechanical components of this device are without potential ignition sources and/ or hot faces. They are not subject to ATEX 95 (94/9/EC). All electronic accessories, on the other hand, meet ATEX requirements.



HON 655-DP

HON 655-DP is a standard design pneumatic pilot for gas pressure regulators according to DIN EN 334. It can be used for both outlet and differential pressure control (for flow restriction by means of orifice plate on downstream site).



По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231 Ангарск (3955)60-70-56 Архангельск (8182)63-90-72 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 **Благовещенск** (4162)22-76-07 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Владикавказ (8672)28-90-48 Владимир (4922)49-43-18 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 **Екатеринбург** (343)384-55-89 Иваново (4932)77-34-06 **Ижевск** (3412)26-03-58 **Иркутск** (395)279-98-46 Казань (843)206-01-48

Калининград (4012)72-03-81 **К**алуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Коломна (4966)23-41-49 Кострома (4942)77-07-48 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курган (3522)50-90-47 Курск (4712)77-13-04 Липецк (4742)52-20-81 Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Ноябрьск(3496)41-32-12

Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16 Пермь (342)205-81-47 Петрозаводск (8142)55-98-37 Псков (8112)59-10-37 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саранск (8342)22-96-24 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13 Сургут (3462)77-98-35

Тамбов (4752)50-40-97 **Тверь** (4822)63-31-35 Тольятти (8482)63-91-07 Томск (3822)98-41-53 Тула (4872)33-79-87 Тюмень (3452)66-21-18 Улан-Удэ (3012)59-97-51 Ульяновск (8422)24-23-59 **Уфа** (347)229-48-12 Хабаровск (4212)92-98-04 Чебоксары (8352)28-53-07 **Челябинск** (351)202-03-61 Череповец (8202)49-02-64 **Чита** (3022)38-34-83 Якутск (4112)23-90-97 Ярославль (4852)69-52-93

Сыктывкар (8212)25-95-17

Россия +7(495)268-04-70 Казахстан +7(7172)727-132 Киргизия +996(312)96-26-47

сайт: www.honeywell.nt-rt.ru || эл. почта: hwn@nt-rt.ru